
RFRP Room Thermostat Wireless



Page 1 of 1 **Installation Instructions**







This thermostat can be mounted in the following ways:


1) To a recessed conduit box


2) Directly mounted on wall


3) Table top stand included


Important: Keep this document



















EPH Controls Ireland